



1. Assign location of retaining weir considering the space requirement.
2. Excavate soil for depth anchor and water-channel according to drawing.
3. Put weir into holes of foundations, align with spirit level and grout in foundations with compressed concrete C20/25.
4. Release for play after concrete foundations have set.

Please take care that all special tools (e.g. special Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the responsible persons.