



1. Assign a device location considering the (minimum) space requirement.
2. Excavate soil for foundation, according to drawing. Please note: To achieve maximum stability and a safe installation, a moderate level of soil solubility is required.
3. Pour in a drain layer of gravel of approx. 10 cm thickness between the bottom of the post and plain base of foundation.
4. Place item into the foundation hole. Play level mark (=welding line) complies with the installation depth.
5. Grout foundation with compressed concrete C20/25, chamfer and round off the edges, cover the foundation with an appropriate surfacing material.
6. Release for play after concrete foundations have set.

Please ensure that all special tools supplied (e.g. Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the persons responsible.

