



1. Assign location of equipment considering the space requirement (impact area).
2. Excavate soil for depth anchorage, according to drawing.
Please note: To achieve a maximum of stability and a safe installation a normal level of soil solubility is required.
3. Put the pre-assembled K&K Balance catwalk into the holes, brace it temporarily and align it with spirit level.
4. In case of light soil it is recommended to cover the depth anchors and the bottom plates with required dimension (0,80x0,50x0,10m) with approx. 10 cm compressed concrete C20/25.
5. Backfill foundation holes and cover the play level with capable material.
6. Release for play after the concrete foundations have set.
7. Please take care that all special tools (e.g. special Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for a safety management (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the responsible persons.