

- 1. Assign a device location considering the space requirements.
- Excavate soil for foundations, according to drawing.
 Please note: To achieve maximum stability and a safe installation, a moderate level of soil solubility is required.
- 3. Pour in a drain layer of gravel of approx. 10 cm thickness between the bottom of the posts and plain base of foundation.
- 4. Place posts type A into the respective foundation hole. Play level mark complies with the installation depth.
- 5. Grout foundations with compressed concrete C20/25, chamfer and round off the edges, cover the foundations with appropriate surfacing material.
- 6. Release for play after concrete foundations have set.
- 7. According to maintenance instructions, check all screw connections after 4–5 weeks and retighten, if necessary.

Please ensure that all special tools supplied (e.g. Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the persons responsible.





