

play equipment

Climbing combination

item number

055411702

product description (page 1)




play equipment

item number

Climbing combination

055411702
<https://kaiser-kuehne.com/products/?lang=en>

product data



(without scale)

installation

play equipment [m]	l	4,45
	w	2,90
	h	2,45
minimum space [m]	l	8,45
	w	6,55
	h	2,45
impact area [m²]		43,00
free height of fall [m]		2,35
number of mechanics		2
assembly time [hrs]		4
lifting device		no
single weight [kg]		30
total weight [kg]		240

foundations

l [m]	w [m]	h [m]	vol [m³]	qty
0,30	0,30	0,40	0,036	2
0,40	0,40	0,60	0,096	6
			0,648	8

usage

areas of use	public playgrounds			
activities	climbing	sporting activity		
age groups	4+			
number of users	14			
inclusion	Individual games		Functional play	
	Speed		Balancing	
	Group games		Altitude experience	
	Coordination		Parallel play	

play equipment
item number

Climbing combination

055411702

variants

17756 *Classic*



30161 *Aloha*



30162 *Beach*



30163 *City*



30164 *Coral*



30165 *Ice Palace*



30166 *Jungle*



30167 *Mermaid*



30168 *Nature*



30169 *Ocean*



30170 *Pirate*



30171 *Safari*



30172 *Sky*



30173 *Sun*



30174 *Sunny Day*



play equipment

Climbing combination

item number

055411702

variants

30175 *Sweden*

