


play equipment **Standing see-saw**
item number **044277000**

product description (page 1)




play equipment

Standing see-saw

item number

044277000
<https://kaiser-kuehne.com/products/?lang=en>

product data



(without scale)

installation

play equipment [m]	l	2,05
	w	1,75
	h	1,48
minimum space [m]	l	5,06
	w	5,06
	h	1,48
impact area [m²]		20,00
free height of fall [m]		0,95
number of mechanics		1
assembly time [hrs]		1
lifting device		no
single weight [kg]		0
total weight [kg]		175

usage

areas of use	public playgrounds
activities	motion activity
age groups	4+
number of users	6

foundations

l [m]	w [m]	h [m]	vol [m³]	qty
1,20	1,20	0,10	0,144	1
			0,144	1

inclusion

Meeting opportunity	Individual games
Functional play	Balancing
Group games	Coordination

play equipment

Standing see-saw

item number

044277000

variants

34846	17680 <i>Classic</i>	19908 <i>Beach</i>
29848 <i>Aloha</i>	29849 <i>City</i>	29850 <i>Coral</i>
29851 <i>Ice Palace</i>	29852 <i>Jungle</i>	29853 <i>Mermaid</i>
29854 <i>Nature</i>	29855 <i>Ocean</i>	29856 <i>Pirate</i>
29857 <i>Safari</i>	29858 <i>Sky</i>	29859 <i>Sunny Day</i>

play equipment

Standing see-saw

item number

044277000

variants

29860 *Sweden*

