


play equipment **Merry-go-round (1,50)**
item number **043322000**

product description (page 1)




play equipment

Merry-go-round (1,50)

item number

043322000
<https://kaiser-kuehne.com/products/?lang=en>

product data



(without scale)

installation

play equipment [m]	l	1,55
	w	1,55
	h	0,90

minimum space [m]	l	5,55
	w	5,55
	h	0,90

impact area [m²]	25,00
free height of fall [m]	0,55

number of mechanics	2
assembly time [hrs]	1

lifting device	no
single weight [kg]	205
total weight [kg]	210

foundations

l [m]	w [m]	h [m]	vol [m³]	qty
0,60	0,60	0,40	0,144	1
			0,144	1

usage

areas of use	public playgrounds
activities	motion activity
age groups	3+
number of users	8

inclusion

Meeting opportunity	Individual games
Functional play	Speed
Balancing	Group games

play equipment

Merry-go-round (1,50)

item number

043322000
variants

4660 <i>Gallery</i>	4661 <i>Cactus</i>	4662 <i>Arctic</i>
		
4663 <i>Atlantic</i>	4664 <i>Coffee Bean</i>	4665 <i>Sapphire</i>
		
4666 <i>Snow White</i>	4667 <i>Deep Black</i>	4668 <i>Poppy</i>
		
4669 <i>Sun</i>	4670 <i>Lemon</i>	4671 <i>Forest</i>
		
4672 <i>Nebula</i>	4673 <i>Sweet Corn</i>	4674 <i>Apricot</i>
		

play equipment

Merry-go-round (1,50)

item number

043322000

variants

4675 *Gravel*



4676 *Fjord*



4677 *Bazaar*



4678 *Tin*



4679 *Willow*



4680 *Patina*



4681 *Highland*



17630 *Classic*



17631 *Ocean*

