


play equipment **Spring see-saw**
item number **044272001**

product description (page 1)




play equipment

Spring see-saw

item number

044272001
<https://kaiser-kuehne.com/products/?lang=en>

product data



(without scale)

installation

play equipment [m]	l	3,10
	w	0,50
	h	0,88
minimum space [m]	l	5,15
	w	2,50
	h	0,88
impact area [m²]		12,00
free height of fall [m]		0,95
number of mechanics		0
assembly time [hrs]		0
lifting device		no
single weight [kg]		0
total weight [kg]		100

foundations

l [m]	w [m]	h [m]	vol [m³]	qty
1,70	0,50	0,10	0,085	1
			0,085	1

usage

areas of use	public playgrounds
activities	motion activity
age groups	3+
number of users	4
















inclusion

Meeting opportunity	Individual games
Functional play	Balancing
Group games	Coordination

play equipment
item number

Spring see-saw
044272001

variants

17677 <i>Classic</i>	17678 <i>Sunny Day</i>	28386 <i>Aloha</i>
		
28387 <i>Beach</i>	28388 <i>City</i>	28389 <i>Coral</i>
		
28390 <i>Ice Palace</i>	28391 <i>Jungle</i>	28392 <i>Mermaid</i>
		
28393 <i>Nature</i>	28394 <i>Ocean</i>	28395 <i>Pirate</i>
		
28396 <i>Safari</i>	28397 <i>Sky</i>	28398 <i>Sun</i>
		

play equipment

Spring see-saw

item number

044272001

variants

28399 *Sweden*

