Instructions for maintenance

In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the European Standard EN1176-7.



041826701 Hill slide (2,60)

(exemplary colour illustration)

One-time maintenance

☒ Check all screw connections; retighten, if necessary. Cover the screws with protective screw caps.	once, approx. 4-5 weeks after installation

Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
☒ Check cleanliness of playing and safety area. Remove any foreign object	☒	☐	☐	☐	☐	☐
☒ Check cleanliness of sliding surfaces, remove protruding parts, exchange damaged sliding course coverings	☐	☐	☒	☐	☐	☐
☒ In case of drying cracks, remove splinters of wood and chamfer sharp edges	☐	☐	☒	☐	☐	☐
☒ Check tightness of stand construction: stability of (vertical) posts or supports, retighten screw connections, if necessary.	☐	☐	☐	☐	☒	☐
☒ Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.	☐	☐	☐	☐	☒	☐
☒ Check tightness/stability of the connection between stainless steel support and laminated timber post, replace post, if necessary.	☐	☐	☐	☐	☒	☐
☒ Check foundations and structural construction for corrosion or decay, repair or replace if necessary	☐	☐	☐	☐	☐	☒

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).