

## Instructions for maintenance

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

## 0-33240-002 Scoop wheel





## Check all screw connections; if necessary srew down again.

one-time only approx. 4-5 weeks after installation

| Recommendations about regular maintenance   | 1 x weekly | 2 x monthly | 1 x monthly | 4 x yearly | 2 x yearly | 1 x yearly |
|---|------------|-------------|-------------|------------|------------|------------|
| Check cleanliness of play- and safety area, take out alien elements   |            |             |             |            |            |            |
| Check stability of vertical posts, tighten bolt-connections if necessary  |            |             |             |            |            |            |
| Check other component elements for wear and tight connections, tighten connections and replace defective elemens if necessary |            |             |             |            |            |            |
| Check bearings and/or joints for tight fixing and easy-runningfunction, replace an grease if necessary                        |            |             |             |            |            |            |
| Check foundation, foundation anchoring and whole<br>construction for corrosion or decay, repair or replace if<br>necessary.   |            |             |             |            |            |            |

Please note: The mentioned maintainance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)