

Instructions for maintenance

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

Maxi swing 0-40453-000 (4,50)





Check all screw connections; if necessary srew down again.

one-time only approx. 4-5 weeks after installation

>

>

		ekly	month	month	yearly	yearly	arly
	Recommendations about regular maintenance	1 x weekly	2 x mo	1 x mo	4 x yea	2 x yea	1 x yearly
\times	Check cleanliness of play- and safety area, take out alien elements			\square			
\mathbf{X}	Check stability of vertical posts, tighten bolt-connections if necessary						
\times	Check other component elements for wear and tight connections, tighten connections and replace defective elemens if necessary						
\ge	Check chain suspensions for wear, replace if necessary. The nominal chain thickness must not diminish more than 30% (<4,5mm!). Beyond that limit, a chain replacement is indispensable.						
\times	Please note that grub screw inside chain adapter has to be tightened e.g. with Allen wrench or catch stoutly without overwinding the hexagon socket						
\times	Check bearings and/or joints for tight fixing and easy-runningfunction, replace an grease if necessary						
\times	Check rubber parts like seats, hoses, collars etc. for wear, replace if necessary			\square			
\mathbf{X}	Check foundation, foundation anchoring and whole construction for corrosion or decay, repair or replace if necessary.						



Please note: The mentioned maintainance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)