

## Instructions for maintenance

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

## Standard Contact swing 0-40552-000 (2,50)

Check all screw connections; if necessary srew down



one-time only approx. 4-5 weeks

again.	after installation					
Recommendations about regular maintenance	1 x weekly	2 x monthly	1 x monthly	4 x yearly	2 x yearly	1 x yearly
Check cleanliness of play- and safety area, take out alien elements						
Check stability of vertical posts, tighten bolt-connections if necessary						
Check other component elements for wear and tight connections, tighten connections and replace defective elemens if necessary						
Check chain suspensions for wear, replace if necessary. The nominal chain thickness must not diminish more than 30% (<4,5mm) Beyond that limit, a chain replacement is indispensable. Please note that grub screw inside chain adapter has to be tightened e.g. with allen wrench or catch stoutly without overwinding the hexagon socket.						
Tighten grubscrews to chain handle with Allen key using lowfirm screw locking paste without overwinding the hexagon socket						
Check bearings and/or joints for tight fixing and easy-runningfunction, replace an grease if necessary						
Check rubber parts like seats, hoses, collars etc. for wear,replace if necessary						
Check foundation, foundation anchoring and whole construction for corrosion or decay, repair or replace if						



necessary.

Please note: The mentioned maintainance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)