

Instructions for maintenance

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7



Standard Contact swing 0-40553-000 (2,50)



Check all screw connections; if necessary screw down again.

one-time only approx. 4-5 weeks after installation

Recommendations about regular maintenance



Check cleanliness of play- and safety area, take out alien elements

1 x weekly

2 x monthly

1 x monthly

4 x yearly

2 x yearly

1 x yearly



Check stability of vertical posts, tighten bolt-connections if necessary



Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary



Check chain suspensions for wear, replace if necessary. The nominal chain thickness must not diminish more than 30% (<4,5mm) Beyond that limit, a chain replacement is indispensable. Please note that grub screw inside chain adapter has to be tightened e.g. with allen wrench or catch stoutly without overwinding the hexagon socket.



Check bearings and/or joints for tight fixing and easy-runningfunction, replace an grease if necessary



Check rubber parts like seats, hoses, collars etc. for wear,replace if necessary



Check foundation, foundation anchoring and whole construction for corrosion or decay, repair or replace if necessary.

Please note: The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)