
## Instructions for maintenance

© 2014 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com


We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

## 0-41832-701 K&K Wide slide (1,20)



Check all screw connections; if necessary screw down again. Cover screw-head with protecting cap.

one-time only approx. 4-5 weeks after installation



\* NB: Please varnish on an annual basis for the first 4 years, and every two years thereafter!

## Please note:

The mentioned maintainance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)