

Instructions for maintenance

© 2008 Kaiser & Kühne Freizeitgeräte GmbH

Im Südlöh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7



0-43120-000 K&K Rotating disc (0,45)

One-time maintenance



Check all screw connections; if necessary screw down again.

one-time only
approx. 4-5 weeks after installation

Recommendations about regular maintenance



Check cleanliness of play- and safety area, take out alien elements



Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary



Check bearings and/or joints for tight fixing and easy-running function



Check foundation, foundation anchoring and whole construction for corrosion, repair or replace if necessary.



Please note:

The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)