Instructions for maintenance

© 2006 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7



0-43121-000 K&K Rotating disc (0,45)

One-time maintenance

Check all screw connections; if necessary screw down again.

one-time only approx. 4-5 weeks after installation

Recommendations about regular maintenance

 1 x weekly

 1 x weekly

 1 x monthly

 1 x yearly

 1 x yearly

 1 x yearly

 1 x yearly

Check cleanliness of play- and safety area, take out alien elements

Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary

Check bearings and/or joints for tight fixing and easy-running function

Check foundation, foundation anchoring and whole construction for corrosion, repair or replace if necessary.

Please note:

The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)