Instructions for maintenance



In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the European Standard EN1176-7.



approx. 4-5 weeks after installation

044201000 K&K Rocker dog

One-time maintenance

Check all screw connections; retighten, if necessary.

Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
Where appropriate, clean playing sand						
Check cleanliness of playing and safety area. Remove any foreign object						
Where appropriate, check synthetic surfacing material for damages or severe wear, repair or replace, if necessary						
Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.						
Check bearings and/or joints for tight fixing and easy-running function, replace or grease, if necessary (rubber suspension unit for the rocking function)						
Check foundations and structural construction for corrosion or decay, repair or replace if necessary						

once,

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).