

Instructions for maintenance

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

K&K Spring 0-44211-000 see-saw





Check all screw connections; if necessary srew down again.

one-time only approx. 4-5 weeks after installation

Recommendations about regular maintenance	1 x weekly	2 x monthl	1 x month	4 x yearly	2 x yearly	1 x yearly
Check cleanliness of play- and safety area, take out alien elements						
Check other component elements for wear and tight connections, tighten connections and replace defective elemens if necessary						
Check foundation, foundation anchoring and whole construction for corrosion or decay, repair or replace if necessary.						\square

Please note: The mentioned maintainance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)