


Instructions for maintenance

In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the European Standard EN1176-7.



Climbing 055470501 combination

One-time maintenance



Check all screw connections; retighten, if necessary.

once, approx. 4-5 weeks after installation

	Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
	Check cleanliness of playing and safety area. Remove any foreign object						
	Check chains for wear, replace if necessary. The nominal chain thickness must not diminish more than 30% (< 5 mm). Beyond that limit, a chain replacement is indispensable.						
	In case of drying cracks, remove splinters of wood and chamfer sharp edges						
	Where appropriate, check synthetic surfacing material for damages or severe wear, repair or replace, if necessary						
	Check tightness of stand construction: stability of (vertical) posts or supports, retighten screw connections, if necessary.						
	Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.						
\square	Check tension and damages of the climbing ropes, replace if necessary						
	Check foundations and structural construction for corrosion or decay, repair or replace if necessary						

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).