

Instructions for maintenance

In addition to the manufacturer-related service instructions and depending on the purpose of use, we strongly advise the operator/owner to consider the corresponding prescriptions of EN 1176-7 resp. EN 16630.



Balance exerciser on totter springs

(exemplary colour illustration)

One-time maintenance

Che	eck all screw connections; retighten, if necessary.	approx. 4-5 weeks after installation
		_

Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
Check cleanliness of playing and safety area. Remove any foreign object						
Check synthetic running surface for damages or severe wear, repair or replace, if necessary						
Where appropriate, check synthetic fall protection surfacing for damages or severe wear, repair or replace, if necessary						
Check tightness of stand construction: stability of (vertical) posts or supports, retighten screw connections, if necessary.						
Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.						
Check foundations and structural construction for corrosion or decay, repair or replace if necessary						

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).