Instructions for maintenance

© 2015 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 - D-27324 Eystrup - Telephone 0049/4254/93150 - Fax 0049/4254/931524 - E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7



9-41001-715 K&K Tunnel Hill Slide 30°

| One-time maintenance ES | | | | | | |
|--|--|-------------|-------------|------------|------------|------------|
| Check all screw connections; if necessary screw down again. | one-time only approx. 4-5 weeks after installation | | | | | |
| Recommendations about regular maintenance | 1 x weekly | 2 x monthly | 1 x monthly | 4 x yearly | 2 x yearly | 1 x yearly |
| Check cleanliness of play- and safety area, take out alien elements | | | | | | |
| Check stability of vertical posts, tighten bolt-connections if necessary | | | | | | |
| Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary | | | | | | |
| Check slide chutes for cleanliness, take out protruding elements, repair defect sliding sheet metal | | | | | | |
| Check foundation, foundation anchoring and whole construction for corrosion or decay, repair or replace if necessary. | | | | | | |

Please note:

The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)

^{*} NB: Please varnish on an annual basis for the first 4 years, and every two years thereafter!