

Instructions for maintenance

In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the European Standard EN1176-7.



Valve combination 1 1/4" with 0-33195-000A hygienic flush

Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
<input checked="" type="checkbox"/> Check tightness and proper function of the valve combination: smoothly running pumping process, automatic closing process after pumping	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
<input checked="" type="checkbox"/> The valve combination <u>must</u> not be located in water, thus: after rainfalls for instance, check the shaft for a water increase or check, if the valve combination is located in water.	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

For the winter season, we recommend draining of valve combination and pump by taking the following steps:

1. Remove black plastic plugs from the K&K valve combination (a total of 3).
2. Unscrew pump head and take it off.
3. Lift off valve from its seat (visible in pump column after taking off the head).
4. The remaining water between pump and valve combination pours out of the outlets mentioned in item no. 1.
5. Reinsert the black plastic plugs as soon as the pipe is completely empty, reinsert the valve into its seat.
6. Fasten the winter cover plate on top of the pump column and store the pump head.

Restart in spring has to take place by taking the following steps:

1. Unscrew and remove winter plate from water pump column.
2. Set water pump head onto water pump column and fix screws.
3. Refill the pump head: push the small black plastic cap at the low-pressure valve until water flows from the pump.

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).