

Instructions for maintenance

In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the European Standard EN1176-7.



062152701 Play arbour

One-time maintenance	(exemplary colour illustration)			
Check all screw connections; retighten, if necessary. Cover the screws with protective screw caps.	once, approx. 4-5 weeks after installation			

Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
Check cleanliness of playing and safety area. Remove any foreign object						
In case of drying cracks, remove splinters of wood and chamfer sharp edges						
Check rubber parts like seats, hoses, flaps, collars for wear, replace if necessary (here: clock hand)						
Where appropriate, check synthetic surfacing material for damages or severe wear, repair or replace, if necessary						
Check tightness of stand construction: stability of (vertical) posts or supports, retighten screw connections, if necessary.						
Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.						
Check bearings and/or joints for tight fixing and easy-running function, replace or grease, if necessary (bearing behind wheel of fortune)						
Check tightness/stability of the connection between stainless steel support and laminated timber post, replace post, if necessary.						
Check foundations and structural construction for corrosion or decay, repair or replace if necessary						

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).