

Instructions for maintenance

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

K&K Water pump with 0-33131-001 handwheel



Please note:

Installation of the water pump to a pressure water pipe requires a K & K Valve combination (product no. 0 33190 000). In addition note the skeleton data specified in the installation instructions (distance, diameter of pipes, etc)



Check all screw connections; if necessary srew down again.

one-time only approx. 4-5 weeks after installation

₹

₹

Recommendations about regular maintenance	1 x week	2 x month	1 x month	4 x yearly	2 x yearly	1 x yearly
Check cleanliness of play- and safety area, take out alien elements						
Check stability of vertical posts, tighten bolt-connections if necessary						
Check other component elements for wear and tight connections, tighten connections and replace defective elemens if necessary						
Check bearings and/or joints for tight fixing and easy-runningfunction, replace an grease if necessary						
Check rubber parts like seats, hoses, collars etc. for wear, replace if necessary						
Check foundation, foundation anchoring and whole construction for corrosion or decay, repair or replace if necessary.						



During the winter months, we recommend the draining of (valve combination and) pump. See detailed instructions on our current mounting instructions and information about the further initiation in spring time.

Please note: The mentioned maintainance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)