

Instructions for maintenance

In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the European Standard EN1176-7.



044208000 **Rocker mouse**

One-time maintenance

One-time maintenance	(exemplary colour illustration)					
Check all screw connections; retighten, if necessary.	once, approx. 4-5 weeks after installation					
Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
Check cleanliness of playing and safety area. Remove any foreign object						
Check climbing handles for wear, replace if necessary						
Where appropriate, check synthetic surfacing material for damages or severe wear, repair or replace, if necessary						
Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.						
Check bearings and/or joints for tight fixing and easy-running function, replace, if necessary (rubber suspension element for the rocker function).						
Check foundations and structural construction for corrosion or decay, repair or replace if necessary						

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).