

- 2. Excavate soil for foundations, according to drawing.

  Please note: To achieve maximum stability and a safe installation, a moderate level of soil solubility is required.
- 3. Pour in a drain layer of gravel of approx. 10 cm thickness between the bottom of the posts and plain base of foundation.
- 4. Insert reinforcing steel into the corresponding holes of the posts.
- 5. Place posts type A according to the corresponding number (see foundation layout) into the respective foundation hole. Play level mark (=aluminium blind rivet) complies with the installation depth. Align every post by means of the play level mark facing into the same direction (see detail or foundation layout).
- 6. For installation of the pre-assembled components and/or single parts, the screws slightly have to be lubricated with installation paste!
  Tighten all screws <u>after having aligned</u> all components.
  Install the slide exit with an inclination of 5° in sliding direction.
  Screw connections see details in attached list.
- 7. Grout foundations with compressed concrete C20/25, chamfer and round off the edges, cover the foundations with a surface which meets the requirements for impact attenuation so that its critical fall height is equal to or greater than the maximum free height of fall of the equipment (acc. to EN 1176-1). The run-out section fall zone must have surfacing with a critical fall height of at least 1000 mm (acc. to EN 1176-3).
- 8. Release for play after concrete foundations have set.
- According to maintenance instructions, check all screw connections after 4-5
  weeks and retighten, if necessary. Afterwards cover the screw heads with
  protection caps.

Please ensure that all special tools supplied (e.g. Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the persons responsible.

Necessarily insert all attachment parts before tightening the screws. It is NOT possible to insert them afterwards.


Description

Scale **1:50** 

Date 08/14 EB

Page 1/2

Item-No






Item: **0-41162-700** Order: 1299131

K&K Combi slide (2,00)


Location: Building Project:

## 32 x SFRS1230004 Standard bolting of climbing bar, ramp etc. to robinia posts with countersunk holes



per SC	Total	K&K-Item	Marking
1 x	32 x	3300016	Grey domed plastic cover cap SL 36 G
1 x	32 x	3430129	Washer Ø 14 DIN1440 A2
1 x	32 x	3400701	Hexagon head cap screw M12 x 130 DIN931 A2 with screw retention coating/FGB red

## 1 x SFAS1070006 Slide run-out section (up to 2,00 m) on foundation stone bolt assembly



per SC	Total	K&K-Item	Marking
2 x	2 x		Set of stone bolts for slide run-out section M12x160

## 4 x SFES1270007 Reinforcing steel for tubular pedestals



per SC	Total	K&K-Item	Marking
1 x	4 x	2130000	Reinforcing steel Ø 10 x 310 DIN 488

## 1 x SFWZ0000013 Lubricating metal, twin bag (2 x 4 g)



per SC	Total	K&K-Item	Marking
2 x	2 x	5300024	lubricating metal 4g