


free height of fall = 1,59 m



straight steel post

70
0,50x0,70

1:20

- 1. Assign a device location considering the minimum space requirements (impact area).
- Excavate soil for foundations, according to drawing.
 Please note: To achieve maximum stability and safe installation, a moderate level of soil solubility is required.
- 3. Before fastening the posts to the swing crossbeam, slightly lubricate the screws with installation paste!
- 4. Screw steel posts to crossbeam according to drawing, put assembled equipment into foundation holes and align it.
- 5. Grout foundations with compressed concrete C20/25, chamfer and round off the edges and cover with a surface which meets the requirements for impact attenuation so that the critical fall height of the surfacing is equal to, or greater than, the free height of fall of the equipment (acc. to EN 1176-1).
- 6. After concrete foundations have set, attach chains to chain adapters in swing axle: unscrew cheese head screw (M8x20-A2) inside adapter, insert the last chain link and fix it with the screw. Attention: the cheese-head screw slightly has to be lubricated with installation paste! Please note that the cheese-head screw has to be hand tightened e.g. with an Allen key or a catch without overwinding.
 - If necessary, shorten length of chain in order to ensure ground clearance of 0,45 m resp. at least 0,40 m below swing seats.
- 7. Check all screw connections according to maintenance instructions after 4–5 weeks and retighten, if necessary.

Please ensure that all special tools supplied (e.g. Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the persons responsible.

Installation

Item No. 940345220 940348220

Description K&K Swing combination Scale 1:50 Date 02/20 DW