



- 1. Assign a location for the equipment considering the impact area (falling space).
- 2. Excavate soil for ground anchorage, according to drawing. Please note: To achieve maximum stability and a safe installation, a moderate level of soil solubility is required.
- 3. Place pre-assembled unit into the foundation holes, support it temporarily and align it with a spirit level.
- 4. With loose particulate material (e.g. bark, woodchip, gravel or sand), it is essential to cover the base plates of the soil anchors by compressed concrete C20/25 of 10cm thickness (size see top view). Afterwards backfill the foundation holes and compress the soil.
- 5. Cover the impact area with appropriate surfacing material. Thanks to the structural shape of the springs, there is no restriction concerning the soil characteristics.
- 6. According to maintenance instructions, check all screw connections after 4-5 weeks and retighten, if necessary.

Please ensure that all special tools (e.g. Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the persons responsible.

Item-No.

0-44150-000

Description K&K Jumping ring

Scale 1:50

Date 11/12 EB Page 1/1