


additional anchorage on choice at extra charge see additional sheets

impact area
(shock-absorbing surfacing essential)



- 1. Assign a location for the equipment considering the (minimum) space requirements.
- 2. Excavate soil for foundation, according to drawing.

  Please note: To achieve maximum stability and a safe installation, a moderate level of soil solubility is required.
- 3. Grout foundation with compressed concrete C20/25, insert depth anchorage into concrete according to drawing and align it with a spirit level.
- 4. The soil characteristics of the impact area surrounding the equipment must have an appropriate level of shock absorption corresponding to a free height of fall of at least 600 mm (according to EN 1176-5).
- 5. After concrete foundation has set, fix equipment to depth anchorage in the following order: Flange of bearing washer self-locking nut M16.
- 6. According to maintenance instructions, check all screw connections after 4–5 weeks and retighten, if necessary.

Please take care that all special tools (e.g. Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the responsible persons.

Installation


Item No. **043200000** 

Description
Rotating bowl (0,85)


Scale 1:50


Date 07/25 Eb


Page 1/5





<u>4x screw connection:</u> hexagon cap nut DIN 986-M16, zinc-coated; washer DIN 125-17, zinc-coated











- Loosen four screws M16 from the cover panel
- Lift rotating bowl with cover panel from the foundation anchor
- For closure at floor level insert furnished HPL cover together with a set of four washers of 5 mm thickness and appropriate countersunk screws M16x50-A2 (see encircled detail).

Installation

Item No. 1090219

Description removable ground anchor

Scale 1:50

Date 07/25 Eb

Page **5/5**