







- 1. Assign location of equipment considering the space requirement.
- Excavate soil for foundation, according to drawing.
 Please note: To achieve a maximum of stability and a safe installation a normal level of soil solubility is required.
- 3. Put water mill into foundation hole and align it according to drawing. Grout in foundation with compressed concrete C20/25, chamfer the edges and cover foundation with surface (acc. to EN 1176-1).
- 4. Release for play after concrete foundation have set.

Please take care that all special tools (e.g. special Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the responsible persons.

Installation

Item-No. 0-33230-001

Description K&K Water mill

Scale **1:50** Date 04/13 EB

Page 1/1