Instructions for maintenance

In addition to the manufacturer-related service instructions and depending on the purpose of use, we strongly advise the operator/owner to consider the corresponding prescriptions of EN 1176-7 resp. EN 16630.

Climbing pole and 057100001 gym-ring exerciser

One-time maintenance

Check all screw connections; retighten, if necessary.

approx. 4-5 weeks after installation

Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
Check cleanliness of playing and safety area. Remove any foreign object						
Check chain suspensions for wear, replace if necessary. The nominal chain thickness must not diminish more than 30%. Beyond that limit, a chain replacement is indispensable. It might be necessary to warm the U-shaped chain bolt for grub screw dismantling (fitting lubricant).						
Where appropriate, check synthetic surfacing material for damages or severe wear, repair or replace, if necessary						
Check tightness of stand construction: stability of (vertical) posts or supports, retighten screw connections, if necessary.						
Check bearings and/or joints for tight fixing and easy-running function, replace or grease, if necessary.						
Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.						
Check foundations and structural construction for corrosion or decay, repair or replace if necessary						

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).





