

- 1. Assign a device location considering the space requirements (impact area).
- 2. Excavate soil for foundations, according to drawing.

 Please note: To achieve maximum stability and a safe installation, a moderate level of soil solubility is required.
- 3. Pour in a drain layer of gravel of approx. 10 cm thickness between the bent tubes and plain base of foundation.
- 4. Insert reinforcing steel into the corresponding holes of the tubes.
- 5. Place both tubes into the respective foundation hole (see foundation layout). Support them, if necessary. Play level mark (=welding spot) complies with the installation depth.
- 6. Grout foundations with compressed concrete C20/25, cover the foundations with a surfacing material which meets the requirements for impact attenuation so that the critical fall height of the surfacing is equal to, or greater than, the free height of fall of the equipment (acc. to EN 16630).
- 7. Release for play after concrete foundations have set.

Please ensure that all special tools supplied (e.g. Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 16630 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the persons responsible.


Installation

Item No. 0-57602-000

Designation
Flyerbars Part II

Scale 1:50

Date 05/21 EB Page 1/2



Installation

Item No. 0-57602-000 Designation
Flyerbars Part II

Scale 1:50 Date 05/21 EB Page 2/2