



1. Assign location of equipment considering the space requirement.
2. Excavate soil for foundations, according to drawing.  
Please note: To achieve a maximum of stability and a safe installation a normal level of soil solubility is required.
3. Put bench steel frame into holes of foundations (mounting depth = playlevel is marked by blind rivet)
4. Grout in foundations with compressed concrete C20/25 (=PG75), chamfer the edges and cover with a surface which shall meet the requirements for impact attenuation so that the critical height of the surfacing according to EN 1177 shall be equal to or greater than the free height of fall of the equipment (acc. to EN 1176 - 1).
5. Release for play after concrete foundations have set

