



Some additional instructions for the installation of K&K slides

- The specified installation height of the slide=hx must be observed (distance between play level and bottom edge of the fastening flange).
- The starting section of the chute must be installed horizontally.
- All (straight, curved or waved sections) of the slide assembly must be installed with the correct inclination (measured in the centre of the slide trough). This does not apply to the run-out section.
- The run-out section must be installed with an inclination of 5°.



flange fastening 1:10



- 1. Assign a location for the bedway slide considering the space requirements/impact area. Slide direction recommended: north-east or in half-shade of trees.
- 2. Excavate foundation hole for run-out section acc. to drawing. Please observe the additional details given.
- 3. Use e.g. lifting gear to carry the bedway slide to the intended mounting place. Fasten flange of slide entrance using the two holes for M12.
- 4. Grout foundation with compressed concrete C20/25 and insert the stone bolts at the same time.
- 5. Release for play after concrete foundation has set.

Please take care that all special tools (e.g. special Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for a safety management (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the responsible persons.

Installation


Item No. 0-41446-001

Description


K&K Bedway slide (1,40)

Scale 1:50 Date 03/16 EB

Page **1/2**



- Due to forced movement, the entire impact area must have impact attenuating surfacing. The critical fall height of the surfacing shall be equal to, or greater than, the free height of fall of the equipment (see EN 1176-1). Depending on the site profile, the free fall height (hx) and the size of the impact area result from the vertical distance between the bottom of the chute and ground level
- The surfacing material for the impact area within the sliding section must meet the requirements given in table 4 (see EN 1176-1). The shock-absorbing characteristics of any other material to be chosen must be certified in accordance
- The surface around the run-out section shall have a critical fall height of at least 1000mm and shall be provided to at least 2000 mm beyond the run-out section (acc. to EN 1176-3).



Installation

Item No. 0-41446-001 Description

K&K Bedway slide (1,40)

Scale 1:50 Date 03/16 EB Page 2/2